

Proxy-Clean® Instructions 2 Ways

1 Cleaning Lines in Between Flocks (when no animals are present)

With your Qwik Blend Injector at 3%, a 3.8 litre container of Proxy-Clean® cleans 1500 feet of waterline.

Important* Before using Proxy-Clean®, ensure there is an air release from your water system (leave flush ends open).

Always start with an empty barn.

Read safety data sheet before using product.

Step 1 – PREPARE THE WATERLINES

Adjust your water-lines to elbow height to make it easier to work on.

Turn valves on for water-flow. If you have a flush system, turn that on. As well, be sure to include your standpipe. Make sure your water valve for the incoming water is turned on.

If there are no drain lines outside the barn, put a bucket at the end of the line(s) to be flushed.

Once lines have been flushed, turn off the water and proceed to Step 2.

Step 2 – HOOK IN YOUR QWIK BLEND INJECTOR

Undo your medicator hoses and attach your Qwik Blend Injector hoses. Pay attention to the arrow on your Qwik Blend Injector so the waterflow is in the proper direction.

Drop the intake hose directly into the jug of Proxy-Clean®.



Step 3 – CLEAN THE LINES

Turn the valves so the product is pulled through the Qwik Blend Injector.

Watch for fizzing in the bucket or on the ground outside where hoses drain.

Food colouring or dye (without a stabilizer) may also be added to the Proxy-Clean® to aid in recognition.

Once the lines are charged, shut the valves off on the regulator and disconnect the Qwik Blend Injector.

Leave the product in the line for 24 - 72 hours.

Trigger the nipple drinkers with the soft side of a broom or your gloved fingers to get product in the well of the nipples.

After 24 to 72 hours flush all the water lines with fresh water.

Trigger the nipple drinkers again with the soft side of a broom or your gloved fingers to ensure there is fresh clean water in the wells of the drinker.

2 Cleaning Your Lines When Birds are in the Barn

Step 1 – MAKE A STOCK SOLUTION

Mix Proxy-Clean® with water in a 20 Litre/5 gallon pail, to the following stock/premix. Then insert the in-take hose in the pail.

CLEANING LEVEL	PUMP SETTING	WATER QUANTITY	PROXY-CLEAN®
Normal	1:128 or 1:100	20 litres	250 mL
Heavy	1:128 or 1:100	20 litres	600 mL

Step 2 – ADJUST YOUR MEDICATOR

Adjust your medicator to 1:100 or 1:128 (1% or .8%).

Step 3 – CLEAN THE WATER-LINES

Turn the valves so the product is pulled through the medicator.

Run the stock solution through the lines for 10 continuous days. Your hydrogen peroxide strips should eventually read between 50 and 125ppm at the end of the line, depending on the cleaning level of Proxy-Clean® in your stock solution.

Trigger the nipple drinkers with a broom or your gloved fingers to get product into the well of the nipples.

After 10 days flush all the water-lines with fresh water.

Again trigger the nipples with a broom or your gloved fingers to ensure there is fresh clean water in the wells of the drinker.

When administering Proxy-Clean® with animals present, it is a good idea to discontinue the use of chlorine, sanitizer, vaccines or other medications. Resume use of chlorine and/or other sanitizers after treatment is finished.

NOTE: It is recommended that this cleaning/conditioning is done for 24 hours after supplemental products such as acids, electrolytes, essential oils, probiotics and vitamins are added or 7 days after the addition of vaccination products as bacteria, yeasts, molds and fungus use these products for energy.

For more detailed information go to: weedenenvironments.com



Maritimes: Dominic Frappier 1-450-278-0661 dfrappier@jefo.ca
QC: Dominic Frappier 1-450-278-0661 dfrappier@jefo.ca
ON: Nahal Ramezani 1-226-752-8928 nramezani@jefo.ca
MB: Zhenbin Zhang 1-431-373-0844 zzhang@jefo.ca
SK, AB: Ron Jones 1-855-767-5336 rjones@jefo.ca
BC: Jan Breckman 1-855-438-3020 jbreckman@jefo.ca

Weeden Environments is the Canadian Manufacturer's representative for Proxy-Clean®

